


# BEGINNER EV3 PROGRAMMING LESSON



Topics Covered:  
Ultrasonic Sensor



By: Droids Robotics

# LESSON OBJECTIVES

1. **Learn about the Ultrasonic Sensor**
2. **Learn how to use Wait Until Ultrasonic Block**
3. **Learn the difference between the Wait Until Ultrasonic Block and the Ultrasonic Block**

# WHAT IS A SENSOR?

- A sensor lets an EV3 program measure and collect data about its surroundings
- The EV3 sensors include:
  - Color – measures color and darkness
  - Gyro – measures rotation of robot
  - Ultrasonic – measures distance to nearby surfaces
  - Touch – measures contact with surface
  - Infrared – measures IR remote's signals



Image from: [http://www.ucalgary.ca/IOSTEM/files/IOSTEM/media\\_crop/44/public/sensors.jpg](http://www.ucalgary.ca/IOSTEM/files/IOSTEM/media_crop/44/public/sensors.jpg)



# ULTRASONIC

- An ultrasonic sensor measures distance.
- You use it when you need to make sure you are a certain distance away from a target.
- The distance can be measured in inches or centimeters.
- To read the ultrasonic sensor, you use the Ultrasonic Block. To use the ultrasonic to do an action until a distance, you use “Wait Until”

Read Ultrasonic

VS.

Wait for Ultrasonic



# ULTRASONIC CHALLENGE 1


**Challenge:** Make the robot move until it is 20cm away from the wall.

**Step 1:** Make a new program

**Step 2:** Set move to “on”

**Step 3:** Set wait block to use the Ultrasonic

**Step 4:** Set move block to “off”



# CHALLENGE 1 SOLUTION

Challenge: Make the robot move until it is 20cm away from the wall.



Set Move  
Steering block  
to "on"

Set wait block to  
Ultrasonic Sensor-  
>Compare-  
>Distance Inches  
and second input  
(inches) to 5.

Set move  
steering block  
to "off"

# CHALLENGE 2: USE THE FORCE TO CONTROL YOUR ROBOT!



## CHALLENGE 2: PSEUDOCODE

**If the robot is closer than 20cm away from your hand move backward, otherwise move forward.**


## Step 1: Drag a loop from the orange tab

## Step 2: Drag a switch inside loop

## Step 3: Set switch to Ultrasonic


### Step 4: Set move steering block to ON with negative power and place in TRUE

## Step 4: Set move steering block to ON with positive power and place in FALSE






# CHALLENGE 2 SOLUTION



# LEARNING TO MASTER YOUR FORCE

**The previous code kept the robot moving always. This version lets the robot rest if it is between 15-20 centimeters.**



# CREDITS

- This tutorial was created by Sanjay Seshan and Arvind Seshan from Droids Robotics.
- More lessons are available at [www.ev3lessons.com](http://www.ev3lessons.com)
- Author's Email: [team@droidsrobotics.org](mailto:team@droidsrobotics.org)



This work is licensed under a [Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License](https://creativecommons.org/licenses/by-nc-sa/4.0/).